

- (1) INSTALLATION FOR AIRCRAFT THAT PROVIDE A REVERSE ANALOG FLAP VOLTAGE WHERE THE VOLTAGE DECREASES AS THE FLAPS DEPLOY.
- (2) CLEAN = HIGH VOLTAGE, FULL FLAPS = LOW VOLTAGE
- (3) FOLLOW ANALOG FLAP DIAGNOSTICS USING ROTARY SWITCH POSITION 7 PROCEDURE FOUND IN THE CALIBRATION GUIDE

THIS PRINT AND ALL INFORMATION THEREIN IS THE PROPERTY OF DEPOTSTAR

